


Introducing your new Remote Control



Remote control styles may vary slightly



Control Live TV



PAUSE LIVE TV

1. Press to pause live TV.
2. Press or to start watching again.
3. Press or once, twice or 3 times to fast forward and rewind at different speeds.
4. Press to jump ahead to live TV.
5. To activate slow motion, quickly press twice.
6. Press to see an instant replay.

Picture in Picture (PIP)



1. Press to display the small PIP screen.
2. Press again to display the larger PIP screen.
3. Press a third time to hide the PIP screen.
4. Press to trade picture in small screen with picture in full screen.
5. Press to shift location of small screen.
6. To change the channel in the small screen, press or .

Contact Us



Call Toll-Free
1-877-772-2253

email: twcable@neo.rr.com
www.twcneo.com



CABLE + HIGH-SPEED ONLINE + DIGITAL PHONE

Digital Video Recorder

Quick-Start Guide



Welcome to TV on your schedule and your terms! This guide is designed to help you start enjoying the most popular features of your new Digital Video Recorder. Get ready to watch what you want, when you want to watch it, with just the touch of a button on your digital remote control.



CABLE + HIGH-SPEED ONLINE + DIGITAL PHONE

Record Your Favorites

1 RECORD WHILE WATCHING A LIVE SHOW




1. Press **RECORD** on your digital remote to begin recording at any time during the program. (This will record the entire program from the time the channel is tuned.)
2. Select 'Record this show' to confirm your choice.

2 RECORD FROM THE INTERACTIVE PROGRAM GUIDE (IPG)



1. Press **GUIDE** to display the IPG.
2. Highlight the show you want to record and press **RECORD** on your digital remote.
3. Select 'Record this show' to confirm your choice.

Record All Season Long



1. Press **GUIDE** to display the IPG.
2. Highlight the show you want to record and press **RECORD** on your digital remote.
3. Choose 'Record entire series' from the menu, then press **SELECT**.

OR

1. Press **RECORD** while watching Live TV.
2. Select 'Record entire series' from the dialog box.

Record 2 Live Shows

1. Press **RECORD** to record the show you are watching, then press **SELECT**.
2. Go to the second show you'd like to record, press **RECORD**, then press **SELECT**.

Verify Your Show is Recording



1. Press **INFO** to confirm your show is recording. The **RECORD** displays in the show's info banner.

Manage Saved Shows

FIND A SAVED SHOW

1. Press **LIST** to view saved shows.
2. Press **UP** or **DOWN** to highlight a show.

ERASE A SHOW

1. Highlight a show and press **SELECT**, select 'Erase' from the menu.

SAVE A SHOW LONGER/ ERASE A SHOW SOONER

1. Highlight a show and press **SELECT**, select 'Keep longer' from the menu.
2. Press **UP** to increase or **DOWN** to decrease a show's lifespan, press **SELECT**.

Watch Anytime



1. Press **LIST** to access saved shows.



2. Highlight the show you want to watch and press **PLAY**.
- OR
2. If the show has already been viewed, press **SELECT** and choose either 'Play from beginning' or 'Resume playback'.